
Bel Stewart Connector


11118 Susquehanna Trail South Glen Rock, PA 17327

STEWART CONNECTOR UNSHIELDED 2-PIECE 30 SERIES PLUG ASSEMBLY INSTRUCTIONS


Assembly steps 1 - 10:



Remove approximately 1 ¼ inch of Cable Jacket




Separate Pairs and untwist them




Align wires (TIA 568-B shown)



Lay wires into approx. positions in Load Bar



Insert each pair, being careful not to collapse ribs between each pair



Trim wires flush with end of Load Bar



Insert wires and Load Bar into housing



Ensure wires go all the way to front of housing



Crimp wires and strain relief

Page 1 of 2 MN300016-A0

Bel Stewart Connector

11118 Susquehanna Trail South Glen Rock PA 17327

STEWART CONNECTOR UNSHIELDED 2-PIECE 30 SERIES PLUG ASSEMBLY INSTRUCTIONS

Assembly steps 1 – 10 (Cont.):



Assembly Complete

Page 2 of 2 MN300016-A0