

INDASH by PANAVISE®

I-75139-804

Page 1 of 1

MOUNTING LOCATION:

Above center Air Vent V U

TOOLS REQUIRED:

T-25 Torx Driver

Phillips Screwdriver

HARDWARE INCLUDED:

S7-1847 & S7-1848 TOP's

W/(2)-O- 8/32" Acorn Nuts

(1)-A #8 x 9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75139-804

MFG: VOLVO

MODELS & YEARS:

Volvo Semi- VN & VT-Series 02-2014

VHD 2002-2014

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Open cup holder at top of dash. With T-25 Torx Driver remove the (2) screws located under the cup holder openings.

STEP #2: Lift up on the front of the bezel and tilt up the panel that includes the cup holder to release a total of (6) clips. Set panel aside.

STEP #3: Place Part A over the left side flat area and locate the left back screw of the bracket that holds the fuse panel in place. Remove this T-25 screw. Place the mount mounting hole over the screw hole, and replace the screw. The mount will come out just above the air vent. Make sure the mount fits well up to the front of the panel cavity, and that the slots for the clips of the bezel align to allow the top to fit in place. Install the (1) supplied Phillips Screw.

STEP #4: Pick which mount Top you want to install according to the device you are installing. The top with (1) bend fits in a North direction. And the (2) bend part fits with the face going in a South direction.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



T-25 Screw Locations



Tilting and Removal of Top



InDash installed showing North direction



InDash installed showing South direction



02-20-13